

SEAT SLIDER (OPTIONAL)

Lift the lever located in front of the paddle to unlock and slide to the desired position. Release the lever to lock in position.

BACKREST RECLINE

Pull the paddle forward to unlock it, lean back to the desired position. Pull the paddle back to lock in position.

BACK LUMBAR SUPPORT

A revolutionary suspension system shifts up or down (in 5 positions) to create our patented invisible lumbar support. The three pivot points create a convex curve that actively supports the entire back. With both hands, simply lift the back frame and let go at your desired tension. Lift all the way up to the top (4 clicks) to release back to neutral.

**TILT TENSION**

Adjust by turning knob under the front of the chair—clockwise to loosen and counter-clockwise to tighten.

ARM HEIGHT

Lift the arm and release to the desired height. Lift all the way up (6 clicks) to release back to neutral.

SEAT HEIGHT

To raise, lift the paddle while lifting your weight from the seat until you reach the desired height. Release the paddle to lock into place. To lower, lift the paddle allowing your weight to push the seat down to the desired height. Release the paddle to lock into place.