

YOU TOO™

User Guide

SEAT SLIDER (OPTIONAL)

Lift the lever located in front of the paddle to unlock and slide to the desired position. Release the lever to lock in position.

BACKREST RECLINE

To adjust the backrest recline, pull the paddle forward to unlock it, lean back to the desired position. Pull the paddle back to lock in position.

TILT TENSION

Adjust by turning knob—clockwise to loosen and counter-clockwise to tighten.



LUMBAR SUPPORT

Turn the knob so the mesh bows to create a convex curve. Lift the U-shaped frame in increments to the desired height. Raise the frame all the way to the top to release.

SEAT HEIGHT

To raise, lift the paddle while lifting your weight from the seat until you reach the desired height. Release the paddle to lock into place. To lower, lift the paddle allowing your weight to push the seat down to the desired height. Release the paddle to lock into place.