


**These disassembly instructions are also applicable to Foster Sleeper Wide.**



 For material recycling information please refer to the Allseating End of Life Recovery and List of Recycling Facilities, which is available at [www.allseating.com](http://www.allseating.com)

Tools: #2 #3 Phillips Head, Rubber Mallet or Hammer, Allen Key

Skill Set: Good manual dexterity

Estimated Time: 15min per chair

**Lower Seat – 4min.**

Flip the chair on its side so the bottom is visible. Pull out the lower seat. Locate the 2 fasteners attached to the “Stop” positioned at the end of the sliding mechanism and unfasten. Remove the “Stop”. Pull the lower seat outwards to remove from the frame.

**Upper Seat – 4min**

Flip the chair on its side so the bottom is visible. Pull the upper seat outwards and position it an angle (approximately 45degree). Locate the 2 fasteners attached to the “Stop” positioned at the end of the sliding mechanism and unfasten. Remove the “Stop”. Pull the upper seat outwards to remove from the frame.

**Folding Back Seat- 4min**

Flip the chair on its side so the bottom is visible. Unzip the upholstery zipper located at the bottom of the folding back seat. Locate 2 fasteners attached to the mechanism located underneath the folding back seat cover and unfasten. Pull folding back seat upwards to remove from frame.

**Side Panel- 3min**

Flip the chair on its side so the bottom is visible. Locate 4 fasteners attached on each side of the side panel and unfasten. Pull the side panels from the mechanism.