# YOUTOO® User Guide

## BACKREST RECLINE

Pull the paddle forward to unlock it. Lean back to the desired position and pull the paddle back to lock in position.



## BACK HEIGHT ADJUSTMENT

From a seated position, grasp the bottom of the back and pull up to adjust the back height.

### LUMBAR SUPPORT

Turn the knob so the back bows to create a convex curve. Lift the U-shaped frame in increments to the desired height. Raise the frame all the way to the top to release.

For additional information, please visit allseating.com

## For Sales and Customer Service

Email: customerservice@allseating.com

Phone: 1-800-563-3502

## For all other inquiries

Email: info@allseating.com Phone: 905-502-7200

PICTURED | YOUTOO IN BLACK NYLON
T2 ARMS | SYNCHRO TILT MECHANISM | SEAT SLIDER | STANDARD CARPET CASTERS
PATENT PENDING





## TURN THE KNOB TO FIND THE **RIGHT LUMBAR** SUPPORT FOR YOU.

The knob on the back right controls the bow and flex of the mesh to create just the right amount of lumbar support to keep you sitting tall and light on your sit bones for greater comfort and productivity.



## YOUTOO® User Guide

## **SEAT SLIDER (OPTIONAL)**

Lift the lever located in front of the paddle to unlock and slide the seat to the desired position. Release the lever to lock the seat in position.

#### **TILT TENSION**

Adjust tension by turning the knob under the front of the chair-clockwise to loosen and counter-clockwise to tighten.

## SEAT HEIGHT

To raise the seat height, lift the paddle while lifting your weight from the seat until you reach the desired height. Release the paddle to lock into place. To lower the seat, lift the paddle allowing your weight to push the seat down to the desired height. Release the paddle to lock into place.

PICTURED I YOUTOO IN BLACK NYLON

T2 ARMS | SYNCHRO TILT MECHANISM | SEAT SLIDER | STANDARD CARPET CASTERS